

# **2 Point Drum Lifter**

# **Owner's Manual**



# **A** WARNING:

Please read carefully and understand these *ASSEMBLY AND OPERATION INSTRUCTIONS* before operating for the first time. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury and/or affect your warranty.

## Model - DL350

### SAVE THESE INSTRUCTIONS FOR REFERENCE

For future reference, please complete the owner's record below:
Model & Serial Number:
Purchase Date:

Save the receipt, warranty, and this manual. It is important that you read the entire manual to become familiar with this product before you begin using it.

This Drum Lifter has been designed for certain applications only. LES is not responsible for issues arising from modification or improper use of this product such as an application for which it was not designed. We strongly recommend that this product not be modified and/or used for any application other than that for which it was designed.

# Content

1.	Warning3
2.	Operation3
3.	Specification 4
4.	Exploded View & Parts List 4
5.	Warranty 5
6.	EC Declaration of Conformity 6

THANK YOU FOR PURCHASING THIS DRUM LIFTER. FOR YOUR SAFETY AND CORRECT OPERATION, PLEASE CAREFULLY READ THIS INSTRUCTION BEFORE USING IT.

**NOTE:** All of the information reported herein is based on data available at the moment of printing. The factory reserves the right to modify its own products at any moment without notice and incurring in any sanction. So it is suggested to always verify possible updates.

#### WARNING

- Read and understand the entire owner's manual before using the drum lifter.
- This drum lifter is designed for lifting drums in vertical position only.
- The drum must have a top lip.
- Do not load the drum lifter beyond its rated capacity of 350Kgs.
- Inspect the drum lifter before each use. If there is damage or distortion to any part, the drum lifter must be removed from service until it is repaired or replaced.
- Make sure the drum is secured by the lifting arms before raising.
- Do not allow anyone to stand beneath a raised drum.
- Never leave a drum unattended in the raised position.
- Do not use this drum lifter for other than its intended use.
- Failure to comply with these warnings may result in personal injury and/or property damage.


#### 2. OPERATION OF DRUM LIFTER

- 1. Attach the drum lifter vertically to the hook of your hoist, chain block, etc.
- 2. Lower the drum lifter over the drum, and make sure the arms are secured evenly onto the rim of the drum to prevent the drum from tilting.
- 3. Carefully move the drum to desired location. When the drum has been lowered completely to the floor or pallet, allow the drum lifter to slacken and move it away from the drum.

### 3. SPECIFICATION

Capacity	 350Kgs.
Drum Size	 55 gallon (210 litre)
Net Weight	 5Kgs

### 4. EXPLODED VIEW & PART LIST



No.	Description	Size	Qty
1	Fixed Arm		1
2	Split pin	Ф4×35mm	1
3	Clevis pin	Ф19×78mm	1
4	Supporting pin		1

#### 5. WARRANTY

LES ("We" or ""Us") warrants to the original purchaser only ("You" or "Your") that the LES product purchased will be free from material defects in both materials and workmanship, normal wear and tear excepted, for a period of one year from date of purchase. The foregoing warranty is valid only if the installation and use of the product is strictly in accordance with product

instructions. There are no other warranties, express or implied, including the warranty of merchantability or fitness for a particular purpose. If the product does not comply with this limited warranty, Your sole and exclusive remedy is that We will, at our sole option and within a commercially reasonable time,

## MACHINERY (SAFETY) REGULATIONS 2008 AND SUCCESSIVE MODIFICATIONS CONFORMITY DECLARATION



#### WE HEREWITH DECLARE

THAT THE FOLLOWING MACHINE COMPLIES WITH THE APPROPRIATE BASIC SAFETY AND HEALTH REQUIREMENTS OF THE MACHINERY (SAFETY) REGULATIONS 2008 BASED ON ITS DESIGN AND TYPE, AS BROUGHT INTO CIRCULATION BY US.

IN CASE OF ALTERATION OF THE MACHINE, NOT AGREED UPON BY US, THIS DECLARATION WILL LOSE ITS VALIDITY.

MACHINE DESCRIPTION: DRUM LIFTER

MACHINE TYPE: DL350

APPLICABLE EC DIRECTIVES: MACHINERY (SAFETY) REGULATIONS 2008

APPLICABLE HARMONIZED EN ISO 12100:2010, EN ISO 13857:2008

STANDARDS: EN953:1997+A1:2009,

EN349:1993+A1:2008.

MANUFACTURER: LIFTING EQUIPMENT STORE

### THE MACHINERY DIRECTIVE 2006/42/EC AND SUCCESSIVE MODIFICATIONS CONFORMITY DECLARATION



#### WE HEREWITH DECLARE

THAT THE FOLLOWING MACHINE COMPLIES WITH THE APPROPRIATE BASIC SAFETY AND HEALTH REQUIREMENTS OF THE EC DIRECTIVE BASED ON ITS DESIGN AND TYPE, AS BROUGHT INTO CIRCULATION BY US.

IN CASE OF ALTERATION OF THE MACHINE, NOT AGREED UPON BY US, THIS DECLARATION WILL LOSE ITS VALIDITY.

MACHINE DESCRIPTION: DRUM LIFTER

MACHINE TYPE: DL350

APPLICABLE EC DIRECTIVES: EC MACHINERY DIRECTIVE: 2006/42/EC

APPLICABLE HARMONIZED EN ISO 12100:2010, EN ISO 13857:2008

STANDARDS: EN953:1997+A1:2009,

EN349:1993+A1:2008.

MANUFACTURER: LIFTING EQUIPMENT STORE



Distributed by:

# **Lifting Equipment Store**

Unit 7 & 17C Gainsborough Trading Estate
Rufford Road Stourbridge West Midlands DY9 7ND
www.liftingequipmentstore.com