



Hand-held Kerbstone Grab Lifter

Owner's Manual



WARNING:

Please read carefully and understand these ASSEMBLY AND OPERATION INSTRUCTIONS before operating for the first time. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury and/or affect your warranty.

Model – CL2

SAVE THESE INSTRUCTIONS FOR REFERENCE

Thank you very much for choosing an LES product!

For future reference, please complete the owner's record below:

Model & Serial Number: _____

Purchase Date: _____


Save the receipt, warranty, and this manual. It is important that you read the entire manual to become familiar with this product before you begin using it.

This Hand-held Kerbstone Grab Lifter has been designed for certain applications only. LES is not responsible for issues arising from modification or improper use of this product such as an application for which it was not designed. We strongly recommend that this product not be modified and/or used for any application other than that for which it was designed.

For technical questions, please call 01384 567 430.

1. Technical Parameters

Parameter	Value
Clamping Range	0 – 370 mm
Maximum Load Capacity	100 kg
Material	Galvanized steel
Handles	Ergonomic, non-slip grips
Additional Feature	Designed for kerbstones and concrete element handling
Weight	3,5 kg



No.	Part Description	Quantity
1	Replaceable rubber grips	2 pcs
2	Rubber grips for holding the element	2 pcs
3	Bolt	1 pc
4	Holes for span adjustment	1 pc

2. Safety Instructions

1. Use the Hand-held Kerbstone Grab Lifter only on firm, level, and stable ground; never operate on soft, inclined, or uneven surfaces.
2. Do not exceed the tool's maximum load capacity of 100 kg.
3. Ensure that the clamping range (0–370 mm) is properly adjusted before attempting to lift or move any element.
4. Before each use, verify that the lifter is securely clamped onto the kerbstone or concrete block.
5. Never place any part of your body under the load while lifting, moving, or positioning.
6. Inspect the tool visually before every use. If any damage, cracks, or deformations are detected, the tool must be immediately withdrawn from use.
7. Do not modify the tool or use it for applications outside its intended design and load range.
8. Grip the tool only by the ergonomic, non-slip handles; do not hold it by other components.
9. Maintain a safe working distance from others, especially when maneuvering heavy materials.
10. Improper use of this tool may lead to injury or material damage.
11. All servicing and repairs must be carried out by qualified personnel only.

3. Use and Operation

1. Before beginning work, set the clamping range to match the size of the kerbstone or concrete element to be lifted.
2. Grip both handles firmly with both hands and clamp the tool securely onto the load.
3. When lifting manually, always keep your back straight and avoid sudden, jerky, or twisting movements.
4. The Hand-held Kerbstone Grab Lifter is designed for manual operation; do not connect it to mechanical lifting devices.
5. Lower the kerbstone in a slow and controlled manner to its intended position.
6. After use, clean the tool thoroughly and store it in a dry, sheltered place to prevent corrosion.

REMEMBER:

- Do not perform quick, uncontrolled movements or overload the lifter.
- Using the tool for purposes other than lifting kerbstones or concrete blocks can cause serious accidents.

4. Maintenance

1. Lubricate all moving parts regularly to ensure smooth operation and reduce wear.
2. Keep the tool clean and dry. Store it in a place protected from moisture and aggressive substances.
3. Visually inspect the lifter before every use for signs of damage, deformation, or excessive wear. Do not use the tool if any faults are detected.
4. Check the condition of the non-slip handles and make sure they are secure and undamaged.
5. When replacing any components, always use original spare parts. Refer to the technical documentation for correct part numbers.

IMPORTANT:

- Do not modify the tool or use non-original parts, as this may compromise safety and performance.
- All maintenance operations must be carried out by qualified personnel.

VERY IMPORTANT:

- Never use oils, greases, or chemicals that may damage the galvanized surface or rubber grips.
- Do not use the tool if it has been contaminated with substances that may cause corrosion or reduce handling safety.

5. Warranty

LES ("We" or "Us") warrants to the original purchaser only ("You" or "Your") that the LES product purchased will be free from material defects in both materials and workmanship, normal wear and tear excepted, for a period of one year from date of purchase. The foregoing warranty is valid only if the installation and use of the product is strictly in accordance with product instructions. There are no other warranties, express or implied, including the warranty of merchantability or fitness for a particular purpose. If the product does not comply with this limited warranty, Your sole and exclusive remedy is that We will, at our sole option and within a commercially reasonable time, either replace the product or product component without charge to You or refund the purchase price (less shipping). This limited warranty is not transferable.

Limitations on the Warranty

This limited warranty does not cover: (a) normal wear and tear; (b) damage through abuse, neglect, misuse, or as a result of any accident or in any other manner; (c) damage from misapplication, overloading, or improper installation; (d) improper maintenance and repair; and (e) product alteration in any manner by anyone other than Us, with the sole exception of alterations made pursuant to product instructions and in a workmanlike manner.

NOTE: Do Not send this unit to the factory for service without obtaining a "Returned Goods Authorization Number" from the service department. We will not be responsible for goods returned without proper authorization.

**MACHINERY (SAFETY) REGULATIONS 2005
AND SUCCESSIVE MODIFICATIONS
CONFORMITY DECLARATION**



WE HEREWITH DECLARE

THAT THE FOLLOWING PRODUCT HAS BEEN DESIGNED AND MANUFACTURED
IN ACCORDANCE WITH GOOD ENGINEERING PRACTICE TO ENSURE IT IS SAFE WHEN USED AS INTENDED.
THE PRODUCT COMPLIES WITH THE GENERAL SAFETY REQUIREMENTS OF THE
GENERAL PRODUCT SAFETY REGULATIONS 2005.

IN CASE OF ALTERATION OF THE PRODUCT, NOT AGREED UPON BY US, THIS
DECLARATION WILL LOSE ITS VALIDITY.

MACHINE DESCRIPTION: Hand-held Kerbstone Grab Lifter 0–370 mm

MACHINE TYPE: CL2

APPLICABLE EC DIRECTIVES: MACHINERY (SAFETY) REGULATIONS 2005

APPLICABLE HARMONIZED
STANDARDS: EN ISO 12100:2010

MANUFACTURER: LIFTING EQUIPMENT STORE

**THE GENERAL PRODUCT SAFETY DIRECTIVE 2001/95/EC
AND SUCCESSIVE MODIFICATIONS
CONFORMITY DECLARATION**



WE HEREWITH DECLARE

THAT THE FOLLOWING PRODUCT HAS BEEN DESIGNED AND MANUFACTURED
IN ACCORDANCE WITH GOOD ENGINEERING PRACTICE TO ENSURE IT IS SAFE WHEN USED AS INTENDED.
THE PRODUCT COMPLIES WITH THE GENERAL SAFETY REQUIREMENTS OF
DIRECTIVE 2001/95/EC ON GENERAL PRODUCT SAFETY.

IN CASE OF ALTERATION OF THE PRODUCT, NOT AGREED UPON BY US, THIS
DECLARATION WILL LOSE ITS VALIDITY.

MACHINE DESCRIPTION:	Hand-held Kerbstone Grab Lifter 0–370 mm
MACHINE TYPE:	CL2
APPLICABLE EC DIRECTIVES:	2001/95/EC – General Product Safety Directive
APPLICABLE HARMONIZED STANDARDS:	EN ISO 12100:2010
MANUFACTURER:	LIFTING EQUIPMENT STORE



Distributed by:

Lifting Equipment Store

Unit 7 & 17C Gainsborough Trading Estate
Rufford Road Stourbridge West Midlands DY9 7ND

www.liftingequipmentstore.com